



Remote Holder Mounting Instructions

Enclosed is a remote holder which can be attached to the side of your Sheep Auto Drafter.

There are two screw holes located below the Control Bridge on both sides of your Sheep Auto Drafter allowing you to mount the remote holder on the left or right hand side, depending on preference.

Using the two supplied 5/8" 6 gauge countersunk screws, insert the bottom screw first followed by the top screw.

3E2581 07/11



Remote Holder Mounting Instructions

Enclosed is a remote holder which can be attached to the side of your Sheep Auto Drafter.

There are two screw holes located below the Control Bridge on both sides of your Sheep Auto Drafter allowing you to mount the remote holder on the left or right hand side, depending on preference.

Using the two supplied 5/8" 6 gauge countersunk screws, insert the bottom screw first followed by the top screw.

3E2581 07/11



Remote Holder Mounting Instructions

Enclosed is a remote holder which can be attached to the side of your Sheep Auto Drafter.

There are two screw holes located below the Control Bridge on both sides of your Sheep Auto Drafter allowing you to mount the remote holder on the left or right hand side, depending on preference.

Using the two supplied 5/8" 6 gauge countersunk screws, insert the bottom screw first followed by the top screw.

3E2581 07/11



Remote Holder Mounting Instructions

Enclosed is a remote holder which can be attached to the side of your Sheep Auto Drafter.

There are two screw holes located below the Control Bridge on both sides of your Sheep Auto Drafter allowing you to mount the remote holder on the left or right hand side, depending on preference.

Using the two supplied 5/8" 6 gauge countersunk screws, insert the bottom screw first followed by the top screw.

3E2581 07/11

